

# F29315E

# **BOULDER BLUFF** 2-IN-1 PLAYSET

BILT.

Easy step-by-step 3D interactive instructions for this product can be found in BILT<sup>®</sup>. Download today.






MAXIMUM VERTICAL FALL HEIGHT - 9'10" (3m).

CAPACITY - 10 Users Maximum, Ages 3 to 10; Weight Limit 110 lbs. (50 kg) per child. RESIDENTAL HOME USE ONLY. Not intended for public areas such as multi-unit residences, schools, churches, nurseries, day cares or parks.

### **Option 1 - Attached Swing Beam Configuration**





OBSTACLE FREE SAFETY ZONE - 33'-10" x 23'-11 1/2" x 16'-4 7/8" (10.3 m x 7.3 m x 5 m) area requires Protective Surfacing. See page 5.

# **INSTALLATION AND OPERATING INSTRUCTIONS**

### FOR 24/7 ONLINE PARTS REPLACEMENT

### parts.kidkraft.com

KidKraft, Inc. 4630 Olin Road Dallas, Texas 75244 USA

customerservice@kidkraft.com

1.800.933.0771 972.385.0100

### parts.kidkraft.eu

KidKraft Netherlands BV Olympisch Stadion 8 1076 DE Amsterdam The Netherlands

europecustomerservice@kidkraft.com

+31 20 305 8620

M-F from 09:00 to 17:30 (GMT+1)

9409315E

Rev 09/13/2021








### **AWARNING**

To reduce the risk of serious injury or death, please read and follow these instructions. Keep and refer to instructions as needed and pass along to any future owners of this item.


### **Option 2 - Separate Swing Beam Configuration**



OBSTACLE FREE SAFETY ZONE - 24'-10" x 23'-11 1/2" x 16'-4 7/8" (7.6~m~x~7.3~m~x~5~m) area requires Protective Surfacing. See page 5.



OBSTACLE FREE SAFETY ZONE - 22'-3" x 19'-5 1/2" x 13'-1 7/16" (6.8 m x 5.9 m x 4 m) area requires Protective Surfacing. See page 5.





parts.kidkraft.com

Congratulations on purchasing a KidKraft product! Our items are made of high-quality, durable Cunninghamia Lanceolata wood from the cypress family. Lumber from these trees are known for their light weight and excellent strength. The porosity of this wood allows the moisture to absorb and evaporate in the fibers, resisting rot and bugs. Engineered for great play, our products also go through extensive testing for safety. Plus, our team has developed a series of proprietary methods for a simpler, more organized assembly. Less build time and more play time is our motto! However, during assembly if you have any questions or concerns, please reach out. Our Customer Service can help with missing parts, instructions or maintenance.



### **Warnings and Safe Play Instructions**



**CONTINUOUS ADULT SUPERVISION REQUIRED.** Most serious injuries and deaths on playground equipment have occurred while children were unsupervised! Our products are designed to meet mandatory and voluntary safety standards. Complying with all warnings and recommendations in these instructions will reduce the risk of serious or fatal injury to children using this play system. Go over the warnings and safe play instructions regularly with your children and make certain that they understand and follow them. Remember on-site adult supervision is required for children of all ages.



### **WARNING**

#### **SERIOUS HEAD INJURY HAZARD**

Installation over concrete, asphalt, dirt, grass, carpet and other hard surface creates a risk of serious injury or death from falls to the ground. Install and maintain shock absorbing material under and around play-set as recommended on page 3 of these instructions.

#### **COLLISION HAZARD**

Place play-set on level ground at least 2m from any obstruction such as a garage or house, fences, poles, trees, sidewalks, walls, landscape timbers, rocks, pavement, planters, garden borders, overhanging branches, laundry lines, and electrical wires. (See OBSTACLE FREE SAFETY ZONE on cover)

#### **CHOKING HAZARD/SHARP EDGES & POINTS**

Adult assembly required. This product contains small parts and parts with sharp edges and points. Keep parts away from children until fully assembled.

#### WARNING LABEL

Owners shall be responsible for maintaining the legibility of the warning labels.

#### STRANGULATION HAZARD

- NEVER allow children to play with ropes, clotheslines, pet leashes, cables, chains or cord-like items when using this play-set or to attach these items to play-set.
- NEVER allow children to wear loose fitting clothing, ponchos, hoods, scarves, capes, necklaces, items with draw-strings, cords or ties when using this play-set.
- NEVER allow children to wear bike or sport helmets when using this play-set.

Failure to prohibit these items, even helmets with chin straps, increases the risk of serious injury and death to children from entanglement and strangulation.

#### TIP OVER HAZARD

Choose a level location for the equipment. This can reduce the likelihood of the play set tipping over and loose-fill surfacing materials washing away during heavy rains.

DO NOT allow children to play on the play-set until the assembly is complete and the unit is properly anchored.

Never add extra length to chain or rope. The chains or ropes provided are the maximum length designed for the swinging element(s).



## **WARNING** – Safe Play Instructions

- ✓ Observe capacity limitations of your play-set. See front cover.
- ✓ Dress children with well fitting and full foot enclosing footwear.
- Teach children to sit with their full weight in the center of the swing seat to prevent erratic swing motion or falling off.
- Check for splintered, broken or cracked wood; missing, loose, or sharp edged hardware. Replace, tighten and or sand smooth as required prior to playing.
- ✓ Verify that suspended climbing ropes, rope ladders, chain or cable are secured at both ends and cannot be looped back on itself as to create an entanglement hazard.
- On sunny and or hot days, check the slide and other plastic rides to assure that they are not very hot as to cause burns. Cool hot slide and rides with water and wipe dry prior to using.
- ✓ Orientate slide such that it gets the least amount of exposure to the sun.

- Do not allow children to wear open toe or heel footwear like sandals, flip-flops or clogs.
- Do not allow children to walk, in front, between, behind or close to moving rides.
- Do not let children twist swing chains or ropes or loop them over the top support bar. This may reduce the strength of the chain or rope and cause premature failure.
- Do not let children get off rides while they are in motion.
- **X** Do not permit climbing on equipment when it is wet.
- Do not permit rough play or use of equipment in a manner for which it was not intended. Standing on or jumping from the roof, elevated platforms, swings, climbers, ladders or slide can be dangerous.
- Do not allow children to swing empty rides or seats.
- Do not allow children to go down slide head first or run up slide.





### A Protective Surfacing - Reducing Risk of Serious Head Injury From Falls

One of the most important things you can do to reduce the likelihood of serious head injuries is to install shock-absorbing protective surfacing under and around your play equipment. The protective surfacing should be applied to a depth that is suitable for the equipment height in accordance with ASTM F1292. There are different types of surfacing to choose from; whichever product you select, follow these guidelines:

#### Loose-Fill Materials

- Maintain a minimum depth of 9 inches (23 cm) of loose-fill materials such as wood mulch/chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for equipment up to 8 feet (2.45 m) high; and 9 inches (23 cm) of sand or pea gravel for equipment up to 5 feet (1.5 m) high. NOTE: An initial fill level of 12 inches (31 cm) will compress to about a 9-inch (23 cm) depth of surfacing over time. The surfacing will also compact, displace, and settle, and should be periodically raked and refilled to maintain at least a 9-inch (23 cm) depth.
- Use a minimum of 6 inches (16 cm) of protective surfacing for play equipment less than 4 feet (1.22 m) in height. If maintained properly, this should be adequate. (At depths less than 6 inches (16 cm), the protective material is too easily displaced or compacted.)

NOTE: Do not install home playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are not adequate protective surfacing. Ground level equipment -- such as a sandbox, activity wall, playhouse or other equipment that has no elevated play surface -- does not need any protective surfacing.

- Use containment, such as digging out around the perimeter and/or lining the perimeter with landscape edging. Don't forget to account for water drainage.
- Periodically rake, check and maintain the depth of the loose-fill surfacing material. Marking the correct depth on the play equipment support posts will help you to see when the material has settled and needs to be raked and or replenished. Be sure to rake and evenly redistribute the surfacing in heavily used areas.
- Do not install loose fill surfacing over hard surfaces such as concrete or asphalt.

#### Poured-In-Place Surfaces or Pre-Manufactured Rubber Tiles


You may be interested in using surfacing other than loose-fill materials - like rubber tiles or poured-in-place surfaces.


- Installations of these surfaces generally require a professional and are not "do-it yourself" projects.
- Review surface specifications before purchasing this type of surfacing. Ask the installer/manufacturer for a report showing that the product has been tested to the following safety standard: ASTM F1292 Standard Specification for Impact Attenuation of Surfacing Materials within the Use Zone of Playground Equipment. This report should show the specific height for which the surface is intended to protect against serious head injury. This height should be equal to or greater than the fall height - vertical distance between a designated play surface (elevated surface for standing, sitting, or climbing) and the protective surfacing below - of your play equipment.
- Check the protective surfacing frequently for wear.

#### Placement

Proper placement and maintenance of protective surfacing is essential. Refer to diagram on front cover. Be sure to;

- Extend surfacing at least 6 feet (1.8 m) from the equipment in all directions.
- For to-fro swings, extend protective surfacing in front of and behind the swing to a distance equal to twice the height of the top bar from which the swing is suspended.
- For tire swings, extend surfacing in a circle whose radius is equal to the height of the suspending chain or rope, plus 6 feet (1.8 m) in all directions.





From the CPSC Outdoor Home Playground Safety Handbook. At http://www.playgroundregs.com/resources/CPSC%20324.pdf



### **Instructions for Proper Maintenance**

Your KidKraft Play System is designed and constructed of quality materials with your child's safety in mind. As with all outdoor products used by children, it will weather and wear. To maximize the enjoyment, safety and life of your Play Set, it is important that you, the owner, properly maintain it.


#### Check the following at the beginning of the play season:

#### HARDWARE:

- ✓ Check metal parts for rust. If found, sand and repaint using a non-lead paint complying with 16 CFR 1303.
- ✓ Inspect and tighten all hardware. On wood assemblies DO NOT OVER-TIGHTEN as to cause crushing and splintering of wood.



✓ Check for sharp edges or protruding screw threads, add washers if required.



#### SHOCK ABSORBING SURFACING:

✓ Check for foreign objects. Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 3)

#### GROUND STAKES (ANCHORS):

✓ Check for looseness, damage or deterioration. Should firmly anchor unit to ground during use. Re-secure and or replace, if necessary.

#### **SWING HANGERS:**

- ✓ Check that bolts are secure and tight. Quick clips should be completely closed and threaded clips screwed tight.
- ✓ If squeaking occurs lubricate bushings with oil or WD-40®. SWINGS, ROPES AND RIDES:
- ✓ Reinstall if removed during cold season. Check all moving parts including swing seats, ropes, chains and attachments for wear, rust and other deterioration. Replace as needed.
- ✓ Check that ropes are tight, secure at both ends and cannot loop back as to create an entrapment.

#### WOOD PARTS:

- ✓ Check all wood members for deterioration, structural damage and splintering. Sand down splinters and replace deteriorated wood members. As with all wood, some checking and small cracks in grain is normal.
- ✓ Applying a water repellent or stain (water-based) on a yearly basis is important maintenance to maintain maximum life and performance of the product.

#### Check twice a month during play season:

#### HARDWARE:

- ✓ Inspect for tightness. Must be firmly against, but not crushing the wood. DO NOT OVER-TIGHTEN. This will cause splintering of wood.
- ✓ Check for sharp edges or protruding screw threads. Add washers if required.

#### SHOCK ABSORBING SURFACING:

✓ Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 3)

#### Check once a month during play season:

#### SWING HANGERS:

- ✓ Check that they are secure and orientated correctly. Hook should rotate freely and perpendicular to support beam.
- ✓ If squeaking occurs lubricate bushings with oil or WD-40®.

#### **SWINGS AND RIDES:**

✓ Check swing seats, all ropes, chains and attachments for fraying, wear, excessive corrosion or damage.

Replace if structurally damaged or deteriorated.

#### Check at the end of the play season:

#### SWINGS AND RIDES:

✓ To prolong their life, remove swings and store inside when outside temperature is below 32°F/0°C. Below freezing, plastic parts may become more brittle.

#### SHOCK ABSORBING SURFACING:

✓ Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary.

(See Protective Surfacing, page 3)

**If you dispose of your play set:** Please disassemble and dispose of your unit so that it does not create any unreasonable hazards at the time it is discarded. Be sure to follow your local waste ordinances.



### **About Our Wood**

KidKraft Premium Play Systems uses only premium playset lumber, ensuring the safest product for your children's use. Although we take great care in selecting the best quality lumber available, wood is still a product of nature and susceptible to weathering which can change the appearance of your set.

#### What causes weathering? Does it affect the strength of my Play System?

One of the main reasons for weathering is the effects of water (moisture); the moisture content of the wood at the surface is different than the interior of the wood. As the climate changes, moisture moves in or out of the wood, causing tension which can result in checking and or warping. You can expect the following due to weathering. These changes will not affect the strength of the product:

1. **Checking** is surface cracks in the wood along the grain. A post 4" x 4" (101mm x 101mm) will experience more checking than a board 1" x 4" (25mm x 101mm) because the surface and interior moisture content will vary more widely than in

thinner wood.

- 2. **Warping** results from any distortion (twisting, cupping) from the original plane of the board and often happens from rapid wetting and drying of the wood.
- 3. **Fading** happens as a natural change in the wood color as it is exposed to sun-light and will turn a grey over time.

#### How can I reduce the amount of weathering to my Play System?

At the factory we have coated the wood with a water repellent or stain. This coating decreases the amount of water absorption during rain or snow thus decreasing the tension in the wood. Sunlight will break down the coating, so we recommend applying a water repellent or stain on a yearly basis (see your local stain and paint supplier for a recommended product).

Most weathering is just the normal result of nature and will not affect safe play and enjoyment for your child. However if you are concerned that a part has experienced a severe weathering problem please call our consumer relations department for further assistance.

Complete and mail registration card to receive important product notifications and assure prompt warranty service.



### **KidKraft Limited Warranty**

#### **MISSING OR DAMAGED PARTS:**

KidKraft will replace any parts within 90 days from date of purchase found to be missing from or damaged in the original packaging. See Fig.1

Fig. 1 Product Age (All Parts) Consumer Pays

0-90 Days from date of purchase \$0 for Part + Free Shipping

#### **DEFECTS IN MATERIAL AND WORKMANSHIP:**

KidKraft warrants that this product is free from defects in materials and workmanship for a period of one (1) year from the original date of purchase (dated sales receipt and/or product registration is required). This one (1) year warranty covers all parts including wood, hardware, and all accessories (Such as swings, rides, and slides). See Fig. 2

Fig. 2 Product Age (All Parts) Consumer Pays

91 Days to 1 Year \$0 for Part + Free Shipping

#### WOOD ROT, DECAY, AND INSECT DAMAGE:

All wood carries a five (5) year warranty against rot, decay, and insect damage (dated sales receipt and/or product registration is required). Refer to the schedule below for charges associated with replacement of wood parts under this **Limited Warranty.** See Fig. 3

Fig. 3 Product Age (Wood Parts) Consumer Pays

0 Days to 1 Year \$0 for Part + Free Shipping
After 1 Year to 5 Year \$0 for Part + Shipping & Handling

Over 5 Years 100% for Part (if available) + Shipping & Handling

This warranty applies to the original owner and registrant and is non-transferable. Regular maintenance is required to ensure the integrity of this product. Failure by the owner to maintain the product according to the maintenance requirements may void this warranty.

This Limited Warranty does NOT cover:

- Any inspection cost
- Labor and/or costs for replacement of any defective item(s), including but not limited to, professional installer costs
- Incidental or consequential damages, including but not limited to, as a result of set relocation, move and/or reinstall
- Cosmetic defects which do not affect performance or integrity of a part or the entire product
- Vandalism, improper use or installation, or acts of nature, including but not limited to, high winds, fire, and flood
- Minor twisting, warping, checking, or any natural occurring properties of wood that do not affect performance or integrity.
- Any KidKraft product purchased, including but not limited to, a non-approved retailer, auction houses, second-hand, and as-is clearance items.

KidKraft products have been designed for safety and quality. Modifications made to the original product may damage the structural integrity of the unit leading to failure and possible injury. KidKraft cannot assume any responsibility for the modified products. Furthermore, modifications void all warranties.

This product is warranted for **RESIDENTIAL USE ONLY.** Under no circumstance should a KidKraft product be used in public settings such as schools, churches, playgrounds, parks, home and professional day cares and the like. Such use may lead to product failure and potential injury. Public use will void this warranty. KidKraft disclaims all other representations and warranties of any kind, express or implied.



### **Keys to Assembly Success**

#### **Tools Required**

- Tape Measure
- · Carpenters Level
- Carpenters Square
- Claw Hammer
- · Standard or Cordless Drill
- Rubber Mallet
- #1 Phillips, #2 Robertson and Screwdriver
- · Ratchet with extension 1/2" (13mm) & 9/16"(14 mm) sockets

Where this is shown, 2 or 3 people

are required to safely complete the


step. To avoid injury or damage

to the assembly make sure to get

- · Open End Wrench 1/2" (13mm) & 9/16"(14 mm)
- · Adjustable Wrench
- 1/8"(3mm) & 3/16"(5mm) Drill Bits
- 3/16" Hex Head Allen Wrench Driver Bit
- 3/16"(5mm) Hex Key
- 8' (2.4m) Step Ladder
- Safety Glasses
- · Adult Helpers
- Pencil

#### Part Identification Key

On each page, you will find the parts and quantities required to complete the assembly step illustrated on that page. Here is a sample.



#### **Symbols**

Throughout these instructions symbols are provided as important reminders for proper and safe assembly.

This identifies information that requires special attention. Improper assembly could lead to an unsafe or dangerous condition.

Use


Help



Check that set or assembly is properly level before proceeding.

Use Leve1

Pre-drill 1/8"(3mm) & 3/16"(5mm) Bit



Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.



Tighten




Measure Distance

Use

Help

Check that assembly is square

help!



Use a measuring tape to assure proper location.



Square

This indicates time to tighten bolts, but not too tight! Do not crush the wood. This may create splinters and cause structural damage.

Lag Assembly

# No






### CAUTION – Protrusion Hazard


Once the assembly is tightened, watch for exposed threads. If a thread protrudes from the T-Nut, remove the bolt and add washers to eliminate this condition. Extra washers have been provided for this purpose.

Proper Hardware Assembly Lag screws require drilling pilot holes to avoid splitting wood. Only a flat washer is required. For ease of installation liquid soap can be used on all lag-type screws.

For bolts, tap T-Nut into hole with hammer. Insert the hex bolt through lock washer first then flat washer then hole. Because the assemblies need to be squared do not completely tighten until instructed. Pay close attention to diameter of the bolts. 5/16" (8mm) is slightly larger than 1/4" (6.4mm).

Note: Wafer head bolts with blue lock tight or a bolt with a Ny-Lok nut do NOT require a lock washer.






Before mounting Lag Screw, use factory drilled holes as guides to drill 1/8" (3.2mm) pilot holes


T-Nut

(Hammer into place)






europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)











1x - 10244 - 15.9 x 76.2 x 493 mm - 38110244
<u>: · · : 5/8" X 3" X 19 7/16"</u>
7x - 10245 - 15.9 x 133.4 x 493 mm - 38110245
5/8" X 5 1/4" X 19 7/16"
1x - 10246 - 34.9 x 63.5 x 1330.9 mm - 35810246
/ <u>:/</u> / <u>:/</u> 1 3/8" X 2 1/2" X 52 3/8"
1x - 10247 - 34.9 x 63.5 x 1330.9 mm - 35810247
<u>/;/ /;/ /;/ /;/                       </u>
4x - 10248 - 23.8 x 82.6 x 489.4 mm - 35810248
15/16" X 3 1/4" X 19 1/4"
2x - 10249 - 15.9 x 76.2 x 528.2 mm - 35810249
. · ·
4x - 10250 - 15.9 x 85.7 x 648.8 mm - 35810250
. 5/8" X 3 3/8" X 25 9/16"
2x - 10251 - 31.8 x 60.3 x 342.8 mm - 38110251
1 1/4" X 2 3/8" X 13 1/2"
2x - 10252 - 31.8 x 76.2 x 656.8 mm - 38110252
<u>•                                    </u>
1x - 10253 - 31.8 x 76.2 x 1117.6 mm - 38110253
o o 1 1/4" X 3" X 44"
4x - 10254 - 15.9 x 85.7 x 526 mm - 35810254
5/8" X 3 3/8" X 20 11/16"
4x - [10255] - 34.9 x 63.5 x 171.4 mm - 38110255
1 3/8" X 2 1/2" X 6 3/4"
4x - 10590 - 34.9 x 63.5 x 215 mm - 38110590
1 3/8" X 2 1/2" X 8 1/8"
1 0/0 X2 1/2 X 0 1/0
3x - 10256 - 23.8 x 85.7 x 963.2 mm - 35810256
: 15/16" X 3 3/8" X 37 15/16"






1x - 10266 - 15.9 x 114.3 x 1028.7 mm - 38110266 · : 5/8" X 4 1/2" X 40 1/2" 1x - 10267 - 15.9 x 114.3 x 1181.2 mm - 38110267 . : : 5/8" X 4 1/2" X 46 1/2" 2x - 10268 - 31.8 x 76.2 x 1000 mm - 38110268 1 1/4" X 3" X 39 3/8" 2x - 10269 - 31.8 x 76.2 x 817.4 mm - 38110269 /-------------------------/ 1 1/4" X 3" X 32 3/16" 2x - 10270 - 31.8 x 76.2 x 817.4 mm - 38110270 · · · · · · · 1 1/4" X 3" X 32 3/16" 1x - 8965 - 31.75 x 76.2 x 514.4 - 3818965 1 1/4" x 3" x 20 1/4" 1x - 10271 - 31.8 x 76.2 x 749.58 - 38110271 1 1/4" x 3" x 29 1/2" 1x - 10588 - 15.9 x 76.2 x 1028.7 mm - 38110588 · · · · · 5/8" X 3" X 40 1/2" 1x - 10589 - 15.9 x 76.2 x 1181.2 mm - 38110589 2x - 10638 - 15.9 x 63.5 x 76.2 mm - 38110638 [· ·] 5/8" x 2 1/2" x 3"












parts.kidkraft.com




europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)



### **Hardware Identification (Actual Size)**








- 5/16" - 51303300



**9 x (FW0)** - 3/16" - 51103100

(FW20) - 3/8" - 51103801 9.5mm

**105** x (FW2) - 5/16" - 51103300 7.9mm



58 x (LW2)

8 x (FW6) - #12 - 9299500



**70 x (LN1)** - 1/4" - 54303200 6.4mm





**31** x (**LN2**) - 5/16" - 54303300


**1 x TN1** - 1/4" - 54503200



64 x TN2 - 5/16" - 54503300 7.9mm




**46** x (**S0**) - #8 x 7/8" - 52933505 22.2mm




**23** x (**S6**) - #12 x 1" - 52433610



**3 x (\$10**) - #8x 1" - 52433510 25.4mm



**2** x (**S5**) - #8 x 1/2" - 52433502 12.7mm




**3 x (S37**) - #7 x 5/8" - 52433009 15.9mm




**280 x (S20)** - #8 x 1-3/8" - 52043516 34.9mm





- #8 x 1-3/4" - 52043513 44.5mm



**56 x (S3)** - #8 x 2-1/2" - 52043522 63.5mm








**10 x (S24**) - #10 x 4" - 52043940 101.6mm









parts.kidkraft.com

### **Hardware Identification (Actual Size)**



**europecustomerservice@kidkraft.com +31 20 305 8620** M-F from 09:00 to 17:30 (GMT+1)







parts.kidkraft.com

**6x** - 9201950

**1x** - 9200131

1x - 9200283 **1x** - 9200285

**2x** - 9200144

**2x** - 9200143

(3)



2x - 9320130

2x - 9320131

1x - 9200286

2x - 9200149





6x - 9200025

8x - 9200020




1x - 3200087 (2pk)

**1x** - 9200151

4x - 9201530




2x -9502020



**4x** -9502045





**20 x (\$0)** - #8 x 7/8" - 52933505 22.2mm

Ammun -

**2x** - 9200632

2x - 9200647 •



**4x** - 9200633

2x - 9200675



Ð

### Included in hardware kit



4x - (9200167)

1x - D1 (9200015)


**1x** - 1/8" x 3" (3.2 x 76.2mm) (9300183)

1x - 3/8" (9.52mm) (9300184)






### 1 Inventory Parts - Read This Before Starting Assembly



- **A.** This is the time for you to inventory all your hardware, wood and accessories, referencing the parts identification sheets. This will assist you with your assembly.
  - The wood pieces will have the key number stamped on the ends of the boards. Organize the wood pieces by step, as per the key numbering system below.



- Please refer to Page 9 for proper hardware assembly.
- Each step indicates which bolts and/or screws you will need for assembly, as well as any flat washers, lock washers, t-nuts or lock nuts.
- **B.** If there are any missing or damaged pieces or you need assistance with assembly please contact the consumer relations department directly. <u>Call us before going back to the store.</u>

1.800.933.0771 or 972.385.0100 customerservice@kidkraft.com canadacustomerservice@kidkraft.com For online parts replacement visit https://parts.kidkraft.com/

+31 20 305 8620 europecustomerservice@KidKraft.com For online parts replacement visit https://parts.kidkraft.eu/

- C. Read the assembly manual completely, paying special attention to EN71 and ASTM warnings; notes; and safety/maintenance information on pages 1 - 9.
- **D.** Before you discard your cartons fill out the form below.
  - The Batch # is located on the end of each carton. The tracking number is located on the KidKraft ID Plaque (9320371).
  - Please retain this information for future reference. You will need this information if you contact the Consumer Relations Department.


MODEL NUMBER: F29315E		
Batch #: (Box 1)	Batch #: (Box 4)	
Batch #: (Box 2)	Batch #: (Box 5)	
Batch #: (Box 3)	Batch #: (Box 6)	
TRACKING NUMBER (from ID Plaque):		







# Assemble T-Nuts first with hammer! Note hole orientation.



**Wood Parts** 

1 x 10636 31.8 x 76.2 x 1479.6mm (1 1/4" x 3" x 58 1/4")

1 x 10216 31.8 x 76.2 x 1117.6mm (1 1/4" x 3" x 44")


**Hardware** 

1 x (WB2) 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, LW2, TN2)












Assemble T-Nuts first with hammer! Note hole orientation.



**Wood Parts** 

1 x 10224 31.8 x 76.2 x 1479.6mm (1 1/4" x 3" x 58 1/4")

1 x 10636 31.8 x 76.2 x 1479.6mm ( 1 1/4" x 3" x 58 1/4")

<u>Hardware</u>

2 x (WB2) 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, LW2, TN2)

**Other Parts** 


2 x 9201530




parts.kidkraft.com








**Assemble T-Nuts first with hammer!** 





#### Wood Parts

1 x 10215 31.8 x 76.2 x 1117.6mm (1 1/4" x 3" x 44")


1 x 10217 31.8 x 76.2 x 565.1mm (1 1/4" x 3" x 22 1/4")

#### **Hardware**

5 x (WB2) 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, LW2, TN2)

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)






Wood Parts
1 x 10218 31.8 x 38.1 x 410.2mm (1 1/4" x 1 1/2" x 16 1/8")

Hardware 2 x (s<sub>3</sub>) #8 x 63.5mm (#8 x 2-1/2")



customer service @kidkraft.com1.800.933.0771 972.385.0100

26





1 x 9367 31.8 x 680.6 x 2218.2mm (1 1/4" x 26 13/16" x 87 5/16")

1 x 9368 31.8 x 1117.6 x 2218.2mm (1 1/4" x 44" x 87 5/16")

**Hardware** 

4 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2")











Pre-drill holes using a 3/16" drill bit.






<u>Wood Parts</u> 1 x 31.8 x 680.6 x 2218.2mm (1 1/4" x 26 13/16" x 87 5/16")

**Hardware** 

4 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2")




parts.kidkraft.com




Hardware 6 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2")

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)





parts.kidkraft.com





2 x 10219 38.1 x 38.1 x 1111.6 mm (1 1/2" x 1 1/2" x 43 3/4")


#### **Hardware**

6 x (s<sub>3</sub>)#8 x 64mm (#8 x 2-1/2")

3 x (WB10) 7.9mm x 66.6 mm (5/16 x 2-5/8")(TN2)

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)








2 x (G35) 7.9mm x 82.6 mm (5/16 x 3-1/4") ( FW2,FW20,LW2, LN2)

**Other Parts** 

2 x 9200167



parts.kidkraft.com




1 x 10228 31.8 x 76.2 x 965.1 mm (1 1/4" x 3" x 38") 2 x 10229 31.8 x 76.2 x 1435.1 mm (1 1/4" x 3" x 56 1/2")


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)





# Assemble T-Nuts first with hammer!





#### **Wood Parts**

1 x 10228 31.8 x 76.2 x 965.1 mm (1 1/4" x 3" x 38")

1 x 10230 31.8 x 76.2 x 901.5 mm (1 1/4" x 3" x 35 1/2")

#### **Hardware**

4 x WB8 7.9mm x 60.3 mm (5/16 x 2-3/8")(TN2)



parts.kidkraft.com



















**Wood Parts** 

1 x 9369 31.8 x 575.6 x 2218.2mm (1 1/4" x 22 11/16" x 87 5/16")

**Hardware** 

4 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2")

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)





#### **Tube Slide Tower**













Pre-drill holes using a 3/16" drill bit.





**Wood Parts** 

1 x 9372 31.8 x 575.6 x 2218.2mm (1 1/4" x 22 11/16" x 87 5/16")

**Hardware** 

4 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2")



parts.kidkraft.com














TN2

9398

FW2

WB2

FW2

LW2


WB2

<u>Wood Parts</u> 1 x 9398 31.8 x 1485.5 x 965.1mm (1 1/4" x 58 1/2" x 38") Hardware 2 x (WB2) 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, LW2, TN2)

Other Parts
2 x 9201530


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)









parts.kidkraft.com







Wood Parts
2 x 10234 38.1 x 38.1 x 959 mm (1 1/2" x 1 1/2" x 37 3/4")


**Hardware** 

6 x (S3)#8 x 64mm (#8 x 2-1/2")

3 x (WB10) 7.9mm x 66.6 mm (5/16 x 2-5/8")(TN2)

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)








2 x (G35) 7.9mm x 82.6 mm (5/16 x 3-1/4") ( FW2,FW20,LW2, LN2)

**Other Parts** 

2 x 9200167



parts.kidkraft.com



2 x 10223 31.8 x 76.2 x 1451.6 mm (1 1/4" x 3" x 57 1/8")

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)


















Assemble T-Nuts first with hammer!

Pre-drill holes using a 3/16" drill bit.








Outside

# **Hardware**


2 x WL5 6.4mm x 63.5 mm (1/4 x 2-1/2")

2 x (s<sub>3</sub>)#8 x 63.5mm (#8 x 2-1/2")







parts.kidkraft.com



Inside Outside






#### **Hardware**

2 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2")

2 x (WB2) 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, LW2, TN2)

2 x (S3)#8 x 63.5mm (#8 x 2-1/2")

SING SOME TRUE



1 x 9370 31.8 x 389.6 x 843.4mm (1 1/4" x 15 5/16" x 33 3/16")


1 x 9371 31.8 x 389.6 x 843.4mm (1 1/4" x 15 5/16" x 33 3/16")

# **Hardware**

4 x WB8 7.9mm x 60.3 mm (5/16 x 2-3/8")(TN2)



parts.kidkraft.com



1 x 10231 31.8 x 76.2 x 901.5 mm (1 1/4" x 3" x 35 1/2")

1 x 10232 31.8 x 63.5 x 843.4 mm (1 1/4" x 2 1/2" x 33 3/16")

<u>Hardware</u>


1 x (WB2) 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, LW2, TN2)


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)












2 x 10232 31.8 x 63.5 x 843.4 mm (1 1/4" x 2 1/2" x 33 3/16")

<u>Hardware</u>

2 x (WB2) 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, LW2, TN2)



parts.kidkraft.com



1 x 10231 31.8 x 76.2 x 901.5 mm (1 1/4" x 3" x 35 1/2")

1 x 10233 31.8 x 60.3 x 901.5 mm (1 1/4" x 2 3/8" x 35 1/2")

# <u>Hardware</u>


3 x WB8 7.9mm x 60.3 mm (5/16 x 2-3/8")(TN2)

2 x (S11) #8 x 50.8mm (#8 x 2")











6 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2")



parts.kidkraft.com







**Underneath View** 

The chain links may come out of the box and cause the bridge not to lay flat. Please shake the bridge to release the chain tension until the bridge lays flat.

**IMPORTANT!** 

Use of 3 flat washers per bolt is required to avoid sharp bolt end protruding past the nut.

<u>Hardware</u>

4 x (WB9) 7.9mm x 54 mm (5/16 x 2-1/8")(FW2 x 3, LN2)

**Other Parts** 

1 x 9365


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)








Note: Structure partly removed for clarity.





**Wood Parts** 


1 x 10221 15.9 x 76.2 x 614 mm (5/8" x 3" x 24 3/16")

<u>Hardware</u>

4 x (S20) #8 x 35mm (#8 x 1-3/8")



parts.kidkraft.com




9 x 10220 15.9 x 114.3 x 614 mm (5/8" x 4 1/2" x 24 3/16")

**Hardware** 

36 x (S20) #8 x 35mm (#8 x 1-3/8")







3 x 10637 15.9 x 76.2 x 723 mm (5/8" x 3" x 28 7/16")

<u>Hardware</u>


12 x (S20) #8 x 35mm (#8 x 1-3/8")




parts.kidkraft.com







Note: Structure partly removed for clarity.



**Wood Parts** 

1 x 10236 15.9 x 114.3 x 477.2 mm (5/8" x 4 1/2" x 18 13/16")

<u>Hardware</u>

4 x (S20) #8 x 35mm (#8 x 1-3/8")

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)








9369



**Note: Structure partly** removed for clarity.

**Evenly space the boards** 



**Wood Parts** 

2 x 10235 15.9 x 76.2 x 477.2 mm (5/8" x 3" x 18 13/16")


6 x 10236 15.9 x 114.3 x 477.2 mm (5/8" x 4 1/2" x 18 13/16")

**Hardware** 

32 x (S20) #8 x 35mm (#8 x 1-3/8")



parts.kidkraft.com





1 x 10238 15.9 x 101.6 x 345.2 mm (5/8" x 4" x 13 9/16")


**Hardware** 

4 x (S20) #8 x 35mm (#8 x 1-3/8")













**Note: Structure partly** removed for clarity.

**Evenly space the boards** 





**Wood Parts** 

1 x 10237 15.9 x 82.6 x 345.2 mm (5/8" x 3 1/4" x 13 9/16")


7 x 10238 15.9 x 101.6 x 345.2 mm (5/8" x 4" x 13 9/16")

**Hardware** 

32 x (S20) #8 x 35mm (#8 x 1-3/8")




parts.kidkraft.com





Note: Structure partly removed for clarity.

**Evenly space the boards** 



**Wood Parts** 

2 x 10239 15.9 x 72.6 x 961.1 mm (5/8" x 2 7/8" x 37 13/16")

**Hardware** 

8 x (S20) #8 x 35mm (#8 x 1-3/8")


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)













# **Underneath Lower Deck View**





# **Underneath Higher Deck View**

**Wood Parts** 

4 x 10240 31.8 x 76.2 x 381 mm (1 1/4" x 3" x 15")


**Hardware** 

4 x (S4) #8 x 76.2mm (#8 x 3")

4 x (s<sub>3</sub>)#8 x 63.5mm (#8 x 2-1/2")



parts.kidkraft.com





7 x 10245 15.9 x 133.4 x 493 mm (5/8" x 5 1/4" x 19 7/16")

2 x 10243 34.9 x 63.5 x 1349.3 mm (1 3/8" x 2 1/2" x 53 1/8")


#### **Hardware**


24 x (\$7)#12 x 50.8mm (#12 x 2")

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1) Con the Table of t










1 x 10244 15.9 x 76.2 x 493 mm (5/8" x 3" x 19 7/16")

<u>Hardware</u>

4 x (S20) #8 x 35mm (#8 x 1-3/8")



parts.kidkraft.com



Hardware 2 x (\$20) #8 x 35mm (#8 x 1-3/8")

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)






# Pre-drill holes using a 3/16" drill bit.










<u>Hardware</u>

4 x (S7) #12 x 50.8mm (#12 x 2")



parts.kidkraft.com





europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)











1 x 10246 34.9 x 63.5 x 1330.9 mm (1 3/8" x 2 1/2" x 52 3/8")

1 x 10247 34.9 x 63.5 x 1330.9 mm (1 3/8" x 2 1/2" x 52 3/8")


4 x 10248 23.8 x 82.6 x 489.4 mm (15/16" x 3 1/4" x 19 1/4")

# <u>Hardware</u>

16 x (S3) #8 x 64mm (#8 x 2-1/2")



parts.kidkraft.com




europecustomerservice@kidkraft.com +31 20 305 8620


M-F from 09:00 to 17:30 (GMT+1)












# **Hardware**

2 x (\$20) #8 x 35mm (#8 x 1-3/8")



parts.kidkraft.com




# **Assemble T-Nuts first with hammer!**











#### **Wood Parts**

2 x 10252 31.8 x 76.2 x 656.8mm (1 1/4" x 3" x 25 7/8")

1 x 10253 31.8 x 76.2 x 1117.6 mm (1 1/4" x 3" x 44")

#### **Hardware**


2 x (G9) 7.9mm x 63.5mm (5/16" x 2-1/2")( FW2, LW2, TN2 )

1 x (WB2) 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, LW2, TN2)












parts.kidkraft.com






4 x (S6) #12 x 25.4mm (#12 x 1")


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)











4 x 10250 15.9 x 85.7 x 648.8 mm (5/8" x 3 3/8" x 25 9/16")

2 x 10251 31.8 x 60.3 x 342.8 mm (1 1/4" x 2 3/8" x 13 1/2")


<u>Hardware</u>

16 x (\$20) #8 x 35mm (#8 x 1-3/8")




parts.kidkraft.com






**Assemble T-Nuts first with hammer!** 

Note: Structure partly removed for clarity.






# **Hardware**

4 x (G9) 7.9mm x 63.5mm (5/16" x 2-1/2")( FW2, LW2, TN2 )


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)












4 x 10590 34.9 x 63.5 x 215 mm (1 3/8" X 2 1/2" X 8 1/8")


4 x 10255 34.9 x 63.5 x 171.4 mm (1 3/8" X 2 1/2" X 6 3/4")

# <u>Hardware</u>

4 x (S4) #8 x 76.2mm (#8 x 3")








**Assemble T-Nuts first with hammer!** 

Note: Structure partly removed for clarity.




### **Hardware**

4 x (G5) 7.9mm x 114.3mm (5/16 x 4-1/2")(LW2,FW2,TN2) 4 x (S4) #8 x 76.2mm (#8 x 3")

4 x (S7) #12 x 50.8mm (#12 x 2")

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)








Note: Structure partly removed for clarity.

Flush



**Wood Parts** 

4 x 10254 15.9 x 85.7 x 526 mm (5/8" x 3 3/8" x 20 11/16)

**Hardware** 


16 x (S20) #8 x 35mm (#8 x 1-3/8")




parts.kidkraft.com









3 x 10256 23.8 x 85.7 x 963.2 mm (15/16" x 3 3/8" x 37 15/16")


2 x 10257 38.1 x 38.1 x 257.1 mm (1 1/2" x 1 1/2" x 10 1/8")

# <u>Hardware</u>

12 x (S15) #8 x 44.5mm (#8 x 1-3/4")










4 x (S3)#8 x 64mm (#8 x 2-1/2")




parts.kidkraft.com









2 x 10263 31.8 x 76.2 x 312 mm (1 1/4" x 3" x 12 5/16")

<u>Hardware</u>


8 x (S11) #8 x 50.8mm (#8 x 2")


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)











2 x 10262 31.8 x 76.2 x 355 mm (1 1/4" x 3" x 14")

<u>Hardware</u>

6 x (S3) #8 x 64mm (#8 x 2-1/2")





parts.kidkraft.com











2 x 9374 28.6 x 979.8 x 492.1mm (1 1/8" x 38 9/16" x 19 3/8")

Hardware 8 x (\$0) #8 x 22.2mm (#8 x 7/8")


2 x 9200


Other Parts
2 x 9200633

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)









1 x 10258 31.8 x 76.2 x 991.4 mm (1 1/4" x 3" x 39 1/16")


1 x 10259 31.8 x 76.2 x 991.4 mm (1 1/4" x 3" x 39 1/16")

### **Hardware**

6 x (S11) #8 x 50.8mm (#8 x 2")




parts.kidkraft.com




europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)







parts.kidkraft.com





europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)











2 x 10262 31.8 x 76.2 x 355 mm (1 1/4" x 3" x 14")

<u>Hardware</u>


6 x (S3) #8 x 64mm (#8 x 2-1/2")



customer service @kidkraft.com1.800.933.0771

972.385.0100

parts.kidkraft.com



2 x 9375 28.6 x751.9 x 567.5mm (1 1/8" x 29 5/8" x 22 5/16")

Hardware 8 x (\$0) #8 x 22.2mm (#8 x 7/8")


Other Parts

2 x 9200633










1 x 10260 31.8 x 76.2 x 780 mm (1 1/4" x 3" x 30 11/16")

1 x 10261 31.8 x 76.2 x 780 mm (1 1/4" x 3" x 30 11/16")

# <u>Hardware</u>

6 x (S11) #8 x 50.8mm (#8 x 2")





**Hardware** 


2 x (\$24) #10 x 101.6mm (#10 x 4")

4 x (S11) #8 x 50.8mm (#8 x 2")

2 x (S4) #8 x 76.2mm (#8 x 3")


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)







parts.kidkraft.com





europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)











**Hardware** 

4 x (S0) #8 x 22.2mm (#8 x 7/8")

**Other Parts** 


2 x 9200647




parts.kidkraft.com









Hardware
14 x (\$0) #8 x 22.2mm (#8 x 7/8")

Other Parts

2 x 9321082

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)







# Note hole orientation












### **Wood Parts**

1 x 10266 15.9 x 114.3 x 1028.7 mm (5/8" X 4 1/2" X 40 1/2") 1 x 10267 15.9 x 114.3 x 1181.2 mm (5/8" X 4 1/2" X 46 1/2") <u>Hardware</u>

8 x (S11) #8 x 50.8mm (#8 x 2")






<u>Hardware</u>


12 x (S20) #8 x 35mm (#8 x 1-3/8")

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)










1 x 9373 28.6 x 781.7 x 647.3mm (1 1/8" x 30 3/4" x 25 1/2")


**Hardware** 

6 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com





1 x 9373 28.6 x 781.7 x 647.3mm (1 1/8" x 30 3/4" x 25 1/2")

Hardware 6 x (S11) #8 x 50.8mm (#8 x 2")

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)





# MOVE FORT TO FINAL LOCATION PRIOR TO STAKING FINAL LOCATION MUST BE LEVEL GROUND












Warning! To prevent tipping and avoid potential injury, stakes must be driven 13"(330mm) into ground. Digging or driving stakes can be dangerous if you do not check first for under-ground wiring, cables or gas lines.

SEE COVER PAGE FOR SAFETY CLEARANCE







### **Hardware**

3 x (s<sub>7</sub>) #12 x 50.8mm (#12 x 2")

2 x (s<sub>6</sub>) #12 x 25.4mm (#12 x 1")

**Other Parts** 

5 x 9290318




parts.kidkraft.com














Hardware
4 x (\$0) #8 x 22.2mm (#8 x 7/8")

Other Parts
1 x 3330909

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)













Important: Use a hand held screw driver and DO NOT over tighten.







# **Hardware**

2 x (S0) #8 x 22.2mm (#8 x 7/8")


2 x (S5) #8 x 12.7mm(#8 x 1/2")

Other Parts

1 x 3330908



parts.kidkraft.com



**Hardware** 2 x (\$0) #8 x 22.2mm (#8 x 7/8") **Other Parts** 


1 x 9320791

1 x 9320889RD

1 x 9320889GG


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)








parts.kidkraft.com




europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)







parts.kidkraft.com




8 x (s7) #12 x 50.8mm (#12 x 2")

8 x (FW6) #12

europecustomerservice@kidkraft.com +31 20 305 8620

M-F from 09:00 to 17:30 (GMT+1)








6 x 53453202 1/4" x 12.7mm



parts.kidkraft.com




### **Other Parts**

18 x 54902200

18 x 53453202 1/4" x 12.7mm


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)







parts.kidkraft.com



### **Other Parts**

6 x 54902200

6 x 53453202 1/4" x 12.7mm


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)










# Warning. Do not over tighten the clamp rings.




After the clamp rings are attached to the elbows, fasten them end to end with two pan bolts and lock nuts









Note: For ease of assembly bottom set of clamp rings can be rotated 90 degrees to install bolts.

### **Hardware**


10 x (PB6) 6.4mm x 25.4 mm (1/4 x 1") (LN1)

**Other Parts** 

**10** x 9300130



parts.kidkraft.com





europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)











### **Wood Parts**

1 x 10271 31.8 x 76.2 x 749.6mm (1 1/4" x 3" x 29 1/2")

1 x 8965 31.75 x 76.2 x 514.4mm (1 1/4" x 3" x 20 1/4")

## <u>Hardware</u>


3 x (S11) #8 x 50.8mm (#8 x 2")

1 x (S4) #8 x 76.2mm (#8 x 3")

1 x \( \text{H8} \) 6.4mm x 108mm (1/4 x 4-1/4")(FW1, LW1, TN1)



parts.kidkraft.com



europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)

















Warning! To prevent tipping and avoid potential injury, stakes must be driven 13"(330mm) into ground. Digging or driving stakes can be dangerous if you do not check first for under-ground wiring, cables or gas lines.

**Hardware** 

1 x (s<sub>7</sub>) #12 x 50.8mm (#12 x 2")

**Other Parts** 

1 x 9290318





parts.kidkraft.com














**Hardware** 

4 x (WL3) 6.4mm x 34.9mm (1/4 x 1-3/8")

4 x (FW1)

**Other Parts** 

2 x 9320240


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)












Pre-drill holes using a 3/16" drill bit.



<u>Hardware</u>

4 x (WL3) 6.4mm x 34.9mm (1/4 x 1-3/8")


4 x (FW1)

Other Parts

2 x 9320240




parts.kidkraft.com




europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)







parts.kidkraft.com



Other Parts

1 x 3200087 (2pk)


europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)













Place Slide centered in the opening.





<u>Hardware</u>

3 x (S7) #12 x 2" (50.8 mm)


3 x (FW1)

**Other Parts** 

1 x 3318115




parts.kidkraft.com



europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)





Wood Parts

1 x 10638 15.9 x 63.5 x 76.2mm (5/8" x 2 1/2" x 3")

<u>Hardware</u>

2 x (S15) #8 x 44.5mm (#8 x 1-3/4")




parts.kidkraft.com





# ATTACH THIS I.D. PLAQUE TO THIS LOCATION ON YOUR PLAY EQUIPMENT!

A Tracking Number is provided to allow you to get critical information or order replacement parts for this specific model.



<u>Hardware</u>

2 x (S37) #7 x 15.87mm (#7 x 5/8")

**Other Parts** 


1 x 9320371

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)











Note: Structure partly removed for clarity.



Screws S0 [52933505] included in the Net bag.



Other Parts


2 x 9500720

0 x (S0) 52933505





parts.kidkraft.com












Screws S0 [52933505] included in the Net bag.



**Underneath View** 


**Other Parts** 

10 x (S0) 52933505

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)















Caution: The Spring Loaded Quick Link must be attached to the Heavy Duty Swing Hanger in the closed position.



**Wood Parts** 

1 x 10587 76.2 x 133.4 x 2235.2mm (3" x 5 1/4" x 88")

**Hardware** 

12 x (G7) 7.9mm x 139.7 mm (5/16 x 5-1/2") (LN2, 2 x FW2)

**Other Parts** 

6 x 9201950

9200025



parts.kidkraft.com











# Assemble T-Nuts first with hammer!





### <u>Hardware</u>


1 x (WB7) 7.9mm x 76.2mm (5/16 x3")( FW2 , TN2 )













<u>Hardware</u>


4 x (S18) #6 x 25.4mm (#6 x 1")

**Other Parts** 

1 x 3320353



parts.kidkraft.com



**Wood Parts** 

2 x 2613 50.8 x 76.2 x 2201.9mm (2" x 3" x 86 11/16")

1 x 2615 76.2 x 76.2 x 1294.3mm (3" x 3" x 50 15/16")


**Hardware** 

2 x  $\langle G7 \rangle$  7.9 x 139.7 mm (5/16 x 5-1/2") (LW2, FW2, TN2)


















Assemble T-Nuts first with hammer!

IT IS IMPORTANT THAT THESE BOLTS ARE ATTACHED. THEY WILL MINIMIZE CHECKING OF WOOD.



**Wood Parts** 

1 x 2616 23.8 x 82.6 x 1181.1mm (15/16" x 3 1/4" x 46 1/2")


**Hardware** 

3 x (G4) 7.9mm x 101.6mm (5/16 x 4") (LW2, FW2, TN2)

2 x (WB7) 7.9mm x 76.2mm (5/16 x 3") (LW2, FW2, TN2)



parts.kidkraft.com



# Hardware


5 x (G21) 7.9mm x 95.2 mm (5/16 x 3-3/4") ( FW2 x 2, LW2, LN2)

# Other Parts

1 x 9200144

1 x 9200143





# Option 1 Attached Swing Beam Configuration

Pages 131 - 136

# Option 2 Separate Swing Beam Configuration


Pages 138 - 142














# **Hardware**

2 x (G21) 7.9mm x 95 mm (5/16 x 3-3/4") ( LN2, 2 x FW2, LW2)

1 x  $\langle G7 \rangle$  7.9mm x 139.7 mm (5/16 x 5-1/2") ( LN2, 2 x FW2)

# Other Parts


2 x 9200149

1 x 9200151

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)










Note: Structure partly removed for clarity.



(G5 )




<u>Wood Parts</u> 1 x 10265 76.2 x 76.2 x 260.9mm (3" x 3" x 10 1/4") <u>Hardware</u>

1 x  $\langle G5 \rangle$  7.9mm x 114.3mm (5/16 x 4-1/2")(LW2,FW2,TN2)

10265



parts.kidkraft.com




# **Hardware**


2 x (G21) 7.9mm x 95 mm (5/16 x 3-3/4") ( LN2, 2 x FW2, LW2)

europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)










# **Hardware**

1 x (G22) 7.9mm x 127 mm (5/16 x 5") ( LW2, FW2 x 2, LN2)




parts.kidkraft.com




europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)








parts.kidkraft.com



# Option 2 Separate Swing Beam Configuration


Pages 138 - 142







parts.kidkraft.com



### **Wood Parts**

1 x 2616 23.8 x 82.6 x 1181.1mm (15/16" x 3 1/4" x 46 1/2")


### **Hardware**

3 x (G4) 7.9mm x 101.6mm (5/16 x 4") (LW2, FW2, TN2)

2 x (WB7) 7.9mm x 76.2mm (5/16 x 3") (LW2, FW2, TN2)








5 x (G21) 7.9mm x 95.2 mm (5/16 x 3-3/4") ( FW2 x 2, LW2, LN2)

1 x 9200144

1 x 9200143




parts.kidkraft.com



europecustomerservice@kidkraft.com +31 20 305 8620 M-F from 09:00 to 17:30 (GMT+1)






# SEE PAGE 2 FOR SAFETY CLEARANCE

MOVE FORT TO FINAL LOCATION
PRIOR TO STAKING
FINAL LOCATION MUST BE
LEVEL GROUND

Warning! To prevent tipping and avoid potential injury, stakes must be driven 13"(330mm) into ground. Digging or driving stakes can be dangerous if you do not check first for under-ground wiring, cables or gas lines.



Hardware 4 x (\$7) #12 x 50.8mm (#12 x 2") Other Parts
4 x 9290318



parts.kidkraft.com

# NOTES

# KIDKRAFT Consumer Registration Card

First Name	Initial	Last Name			
Street		Apt. No.			
City		State/Province ZIP/Postal Code			
Country		Telephone Number			
E-Mail Address					
Model Name		Model Number (Box Labels)			
Serial Number (on ID Plaque)					
Date Purchase Purchased From					
MM / DD / YY					
How would you rate this product for quality?  ☐ Excellent ☐ Very Good	□ Av	verage			
How would you rate this product for ease of assembly?					
Excellent Very Good		verage			
How would you rate our instructions?					
☐ Excellent ☐ Very Good	☐ Av	verage			
How would you rate the quality of packaging?	_				
☐ Excellent ☐ Very Good	☐ Av	verage			
Would you recommend the purchase of our prod	ucts to frie	ends and family?			
Yes No					
Comments:					



## MAIL TO:

KidKraft Netherlands BV Olympisch Stadion 8 1076 DE Amsterdam The Netherlands Attention: Customer Service Fill out your registration card online at <a href="https://prdregistration.kidkraft.com/">https://prdregistration.kidkraft.com/</a>

KidKraft would like to say Thank You for your time and feedback.