

INSTALLATION MANUAL 1050 | 1150 Diamond Series



30 Day Technical Support:

Call **01908 317512** and request technical support for aiding your installation.

Replacements Parts: Inside of your warranty period visit:

<u>https://www.insigniashowers.com</u>, click support and make a warranty claim.

Spares/Replacements Parts: Outside of your warranty period visit


https://www.insigniashowers.com/replacement-parts.html

ATTENTION INSTALLERS:

These instructions must be left with the customer CHECK ALL CONTENTS BEFORE BUILD COMMENCES. NO RETURNS CAN BE MADE ONCE THE BUILD HAS STARTED AS IT IS DEEMED ACCEPTANCE OF PRODUCT! WARRANTY REG NO:

To claim your full 3 year warranty, register your shower within 90 days visit:

https://www.insigniashowers.com, click support and register for your warranty



Contents

Installing the Roof23Installing the Fixed Glass Panel24Installing the Seals25Installing the Accessories26Installing the Accessories27Water Valve Connections28Control Panel Connections29Steam Generator Connections30Signing off your shower32Control Panel Operating Instructions33Spare Parts List36
Installing the Seals25Installing the Accessories26Installing the Door Wheels27Water Valve Connections28Control Panel Connections29Steam Generator Connections30Signing off your shower32Control Panel Operating Instructions33
Installing the Accessories 26 Installing the Door Wheels 27 Water Valve Connections 28 Control Panel Connections 29 Steam Generator Connections 30 Signing off your shower 32 Control Panel Operating Instructions 33
Installing the Door Wheels27Water Valve Connections28Control Panel Connections29Steam Generator Connections30Signing off your shower32Control Panel Operating Instructions33
Water Valve Connections28Control Panel Connections29Steam Generator Connections30Signing off your shower32Control Panel Operating Instructions33
Control Panel Connections29Steam Generator Connections30Signing off your shower32Control Panel Operating Instructions33
Steam Generator Connections30Signing off your shower32Control Panel Operating Instructions33
Signing off your shower 32 Control Panel Operating Instructions 33
Control Panel Operating Instructions 33
Spare Parts List 36
Steam Room & Shower Safety Guide 37
Steam Room Usage Guide 38
Bathroom Electrical Zones 39
WEEE Compliance Statement 41

3	Installation Assistance
4	Thank you for your purchase
5	Tips for assembly
6	Braided Hose QR Code/Link
7	Electrical/Pressure/Tool requirements
8	Box contents
9	Installing the Waste and Levelling the Tray
10	Connecting the Framework
11	Applying RubberGum
12	Installing the Left Back Panel and Side Panel
13	Installing the Front Left Corner Upright
15	Connecting the Framework into the Upright
16	Installing the Column
17	Installing the Front Right Corner Upright
19	Installing the Right Side Panel
21	Installing the Right Back Panel
22	Installing the Door Handles, Seals and Magnets

Installation Assistance

Looking for assistance with the Install?

GREAT NEWS!

We have our easy to follow Installation videos live online NOW to make your installation process easier than ever before!

Simply click the link below and watch the installation process.

Shower Install

Please note: this build video is for an Insignia Platinum Shower, however 90% of the process is the same for assembly so it should help you on your way!



Thank you for your recent purchase of an Insignia shower. Please read this booklet with great care to ensure you get the best out of your build and have a shower that will last for many years to come! Like everything, in order to obtain a first class product that will serve you well for many years, the effort and correctness put into the assembly will reflect in the quality of your finish. www.insigniashowers.com

Before we start, here's our 4 top tips which may assist you...

TIP 1—Building Your Shower

This product is suitable for a DIY build, providing you are confident in your DIY abilities. Please look through this build guide and decide on whether you feel confident in undertaking this task. If you are not, seek the services of a professional and show them these instructions before hiring.

TIP 2—Hard Water

Due to the nature of this product we highly advise the purchase and fitting of a water softener.

(Please note: limescale build up may cause damage to your shower and will not be covered under warranty)

TIP 3—Installation

These showers are designed to be free standing and movable from their location should you have the need to replace anything. <u>ALWAYS USE</u> Flexible braided water inlet pipes (not supplied) and not central heating plastic type! Get your WRAS Approved Flexible

Braided Hoses here. (www.insigniashowers.com/wras-approved-braided-hoses.html)

NEVER FIX with rigid pipes, **NEVER FIX** the unit to the wall or floor.

TIP 4—Sealing

When using Insignia's RubberGum, please ensure the product does not come in contact with your silicone as this will cause the RubberGum to fail and will not adhere as intended. Rubbergum is immediately waterproof and will gain additional strength over time.

Ssential

Have you got yours? Essential for your shower build!

The Insignia WRAS approved flexible braided shower hose is an essential part of your shower build. Desgined specifically for connecting the hot and cold water feeds allowing for an easier installation. Note: These are not available in shops.

Don't worry if you have forgotten to purchase this as we've included this handy link for you! All you need to do is use your smart device and simply point your camera at the QR code to scan it. You can also download a free QR reader app.



Not got a smart device? No problem! Just type the following web link into your web browser:

www.insigniashowers.com/wras-approved-braided-hoses.html



Electrical Requirements	Pressure/Water Requirements	Tools Required
Electrical Requirements STEAM VERSION Voltage Rating 220-240AC Frequency Rating 50Hz Power Rating 3KW NON-STEAM VERSION Voltage Rating 100-240AC Frequency Rating 50/60Hz Power Rating 12v DC/1500 mA Your electrical contractor should understand ALL legal	Pressure/Water RequirementsWe recommend a BAR pressure between 2.5 and 3.4 BAR. If you have a combi boiler system no problem should be experienced. If you have a gravity feed older type installation (hot water tank type usually less than 1 BAR) you will almost certainly need a pump. We cannot advise on which type of pump is used, location or design because all house plumbing layouts vary. This is a job for your installer/plumber. The end delivery however must fall within the scope above.Important Note Do not exceed 3.4 BAR pressure under any circumstances. Warranty is void if so as damage will occur. If you have a combi supply, please use a pressure to the shower.Please Remember that this product is free standing and is	Tools RequiredYou will require:• Scissors• Philips Screwdriver• Knife• Electric Drill• Spirit Level• Safety Gloves• Tape Measure• Safety GlassesParts Required• RubberGum (supplied)
 Your electrical contractor should understand ALL legal requirements of connection before undertaking any work or installation. UNDER NO CIRCUMSTANCES UNDERTAKE THIS YOURSELF!!! Note for electrician: This product comes with 13 amp plug (s) fitted with an RCD unit (steam version only). We leave it this way for you to connect it your own way due to continued additions to current regulations. 1) Connect within current laws and IP directives. 2) (Preferred) Wire into isolated fused feed connecting directly to the house consumer/service box. Always use protection against electrical surge. Your shower should be treated the same as a home computer. A surge protector should eradicate the possibility of either the 	 designed to be pulled away from the wall. Waste connection HOUSE to SHOWER. Always use a McAlpine or similar approved 40mm compression joint fitting. Never use glued joints! Your waste hose is specifically designed not to accept glued joint fittings. Correct compression joint fittings avoid degradation of materials. The water supply pipes must be that of a flexible braided type (not supplied). DO NOT OVERTIGHTEN THE BRAIDED HOSES AS IT CAN CAUSE THE CONNECTION TO POP AFTER A FEW WEEKS OF USE. Always fit easy to get to isolation taps on both hot and cold water supply (not supplied). Just like a dishwasher or washing machine, this product <u>MUST</u> be isolated when not in use. 	 Plumbers Mait (not supplied) Hot and cold isolation valves (not supplied) Suitable McAlpine or similar approved 40mm compression joint fitting. 2x Braided hoses (not supplied) Steam version requires 3. If you haven't purchased these already, simply click the following link below or copy in to any web browser. For ease we have listed the required pack below for your install. Shower cabins with steam require pack 2 https://www.insigniashowers.com/wras-approved-braided-hoses.html

What's in the Boxes?

Вох	Contents	Quantity	\checkmark
Tray	Shower Tray	1	[]
	Waste + Hose	1	[]
	Glass Shelf	1	[]
	Riser Rail for hand shower	1	[]
	Screw Pack	1	[]
	Shower hose	1	[]
Glass Room	Glass Door	1	[]
	Side Panels	1	[]
Column	Complete Column	1	[]
	Hand Shower	1	[]
Backwall	Left Back Panel	1	[]
Pack	Right Back Panel	1	[]
	Font Fixed Panel	1	[]

VERY IMPORTANT


Have you got everything? If not please contact the Insignia directly on **01908 317 512**. Remember <u>NEVER</u> book your tradesman until everything has arrived, been checked and is present. No replacement/missing parts can be obtained free of charge during or after the build. Any claims can only be within the timescale permitted (48 hours after delivery) and always **BEFORE** build.

Framework	Top Rail	1	[]
	Bottom Rail	1	[]
	Outer Fixed Uprights	2	[]
	Inner upright post	2	[]
	Magnetic door seal	1	[]
	Rear flap door seal	1	[]
	Flexible seal (12mm)	1	[]
	Flexible seal (7mm)	1	[]
Roof	Roof with fittings	1	[]


Screw Pack Contents

Product Code	Description	Quantity
SP097	Door Handle	1
SP276	Twin Door Wheels Non-Push	2
SP276A	Twin Door Wheels Push button	2
ST8	8mm Screws	12
ST10	10mm Screws	12
ST16	16mm x 3.5mm Screws	8
ST16	16mm x 4mm Screws	6
ST20 or WN20	20mm Nut and Bolt or Wing Nut	12
AMI01	Jubilee Clip (For steam version only)	1
SW9	Small Washers	20
DB9	Drill Piece	1


Step 1 — Level the Tray and connecting the waste




Step 2 — Connecting the framework




Step 3 — RubberGum the tray




Step 4 — Connecting the left back panel to left side panel




Step 5 — Connecting the left corner upright to the side panel




Step 5 — Connecting the left corner upright to the side panel continued





Step 6 — Connecting the framework into the upright.




www.insigniashowers.com









Step 8 — Corner post to framework connection





Step 8 — Corner post to framework connection continued






Step 9 — Connecting the right side panel continued







Step 10 — **Connecting the right back panel**




Step 11 — Fitting door handle, seals and magnets






Step 13 — Fixed Glass Connection




www.insigniashowers.com


Step 14— Fitting the seals




12mm Seal




7mm Seal




Step 15 — Accessories Installation







Step 19 — Valve/Water Connections



Step 20 — Touch Control Panel Connections






Steam Generator Connections (steam version only)

The steam generator has 3 connections.

- 1. **Steam Outlet:** Connect the white insulated hose to the steam system within your shower as shown in image **A**. Make sure these are fitted in the correct position as they are only attached for transportation reasons only.
- 2. **Water Inlet:** When installing the water line for the steam generator, there are 2 options available:
- Purchase Insignia's WRAS approved braided hoses—different packs are available for different shower types.
- Install a static water line from the shower valve (middle feed) to the steam generator. Even with a static water line, flexible hosing will still be required for the hot and cold water feeds. If you choose this option, please ensure you purchase the correct hose pack from <u>www.insigniashowers.com</u>
- 3. Drain: See next page




Steam Generator Connections

Drain: A— Ensure this is facing the steam generator and is tightened fully, then take the hose connected to the steam drain and trim to a desired length. (Image 1)

Once trimmed, connect the hose to (A) (Image 2) and secure in place with a jubilee clip from the screw pack contents.

Drill Out the spigot (Image 3) on the waste and connect a hose from your accessory box from the spigot (C), to (B) and tighten using the jubilee clip provided.

Signing off your shower



1. Please ensure ALL the connections are watertight including waste, pre-fitted body jets as clips are only lightly tightened in place for transit and can be dislodged, internal and external hoses and steam connections (model dependent)

2. Once you are happy, check the shower functions by switching on the overhead shower and then adjust the selector knob (top knob) to the hand shower and then onto the body jets. Whilst the water is running, check external hoses for any signs or water drips or leaks and tighten accordingly.

Please note, when testing the body jets, water will shoot towards the open doors and the user.

3. Do not aim the hand shower directly at the joints of your shower as this does not fall under "normal showering conditions". However, due to Insignia's unique design of the shower tray, water will only leak back in to the tray so you won't get flooded.

4. Visually check the water flow in to the waste and adjust the feet of the tray accordingly to ensure the direction of the water flows towards to the waste to prevent over puddling (a small amount of puddling is normal).

5. Never use the shower until all checks have been made and the installer is 100% happy in the knowledge no hose leaks are present.

6. Any RubberGum which has squeezed out between the panels and the tray, simply cut off using a sharp, clean knife blade.

7. Now push the shower from it's base into it's final position. **NEVER PUSH THE GLASS OR FRAME** into its final resting position.

Happy Showering!



Control Panel Instructions

Button 1 (Lights)

Once the control panel is switched on, the lights will come on automatically. Press the Light button once and the lights will start to scroll through the multiple colour options. Then to stop the lights on a specific colour simply press the light button again on the desired colour. To turn the lights off press the light button again.

Button 2 (Steam)

To start the steam function, simply press the steam button (which looks like a cloud). To set the time and temperature of the steam session, simply press the mode button (button 3) and then use the arrows to scroll up and down (button 6)

Button 3 (Mode)

This will do nothing on start-up, however it will be your go to button when using steam, radio and Bluetooth options

Button 4 (Padlock)

This is your unlock button. After twenty seconds of inactivity the steam function will lock on the panel. This is done as a safety feature, so it can't be accidentally activated. Other buttons will remain functional whilst in this state of 'lock mode'

Button 5 (Music)

Press once for FM Radio and press twice for Bluetooth. For tuning radio stations or connecting Bluetooth, please see the next page. For volume control, once on the radio or Bluetooth setting press Mode (button 3) then use the left and right arrows to change the volume. The volume is denoted by a number followed by the letters 'db'

Button 6 (Left and Right Arrows)

This will do nothing on start-up, however they are multi-functional depending on what setting you are using. When in the radio setting you can use them to change the station. When using the Bluetooth setting you can skip forward or back tracks in your playlist. You can also control the volume with these arrows as directed above.

Button 7 (Power)

Press once to turn on the panel. Simply press again to turn it off. When powering down the 03 will automatically start and last for approximately 10 minutes. After this the screen will power off.

To see our tutorial videos for operating Insignia control panel's, please search for "Insignia Showers" on YouTube and find our "Insignia Control Panel" Playlist, or you can <u>click here</u>

Infignia

1

4

33

Control Panel Instructions

Connecting to Bluetooth




Step 1

To connect a device via Bluetooth, press the music function button twice (which looks like a musical note) the control panel will then show "INS".

Step 2

Then simply go on your device and pair up with the shower which should be shown as "INS". Once this is complete you will hear a beep to signify you're connected and ready to listen to any music of your choice.



Tuning your radio channels



Step 1

To tune your radio channels firstly press the music function button (which looks like a musical note)



Step 2

Then once the radio is on press and hold the mode button until it starts scrolling.



Step 3

Finally, once the panel has finished scrolling then use the left and right arrows to cycle through all the radio stations that were found.

nds)
nd)
iser bar)
dles
on
i

Parts List

Touch Sensitive Insignia
Control Panel
Hand Shower
Fixed Glass Seals (12mm)
Fixed Glass Seals (7mm)
Light diffuser
Multi-coloured LED light ring
LeakFree Framework
Securing Clip (Black)
LeakFree Framework
Securing Clip (Chrome)
Chrome Knob for Selector/
Water Flow Dial
Water Valve Chrome
Selection Plate

SP300	Waste hose
SP282	Insulated pipe
SP187	Drain Hose
SP234	Vertical steam
	generator/Electric box
SP308	Magnetic door seals
SP310	Rear door seals
SP245	3 port—3 feed non-
	thermostatic valve
SP193	3 Port Selector Cartridge
SP091	Tap cartridge
SP321	LeakFree Column End
	Caps
SP101	UPVC Hose

www.insigniashowers.com

Steam Room & Shower Safety Guide

- 1. Never leave children unattended in the shower or bath.
- 2. Never bath children (under 12) using whirlpool function if fitted.
- 3. Regulate the temperature of water before showering.
- 4. Never allow children to use the steam function. This function is for **ADULTS ONLY**.
- 5. Always be aware of the steam outlet position. Never use in close proximity to the person using it.
- 6. Exit the steam room immediately if feeling dizzy, faint or short of breath.
- 7. Do NOT use the steam room if you're pregnant, have a heart condition, have low or high blood pressure. If you're unsure consult your GP before use.
- 8. If you have any underlying health conditions which you feel could be aggravated by using a steam room, consult your GP before use.
- 9. If you begin to have any issues with your health after using a steam room, stop immediately and consult your GP regarding your symptoms before continuing to use.
- 10. Consult your GP before using the steam room if you're on medication at all, especially with drowsy side effects.
- 11. Never use this shower if you have been drinking alcohol or under the influence of other substances.
- 12. Never use with more than one person unless the shower is designed for this.
- 13. This product is not to be used for washing/bathing animals.
- 14. Always turn power supply off after use.
- 15. Always turn water supply off after use.
- 16. Ensure room is well ventilated after a steam session by using your bathroom extraction fan or opening a window.




Steam Room Usage Guide

- 1. To use the steam room, turn the control panel on. (1)
- 2. Press the steam button (2) and your generator will be fed with water and the heating element will begin to heat the water to create steam. (You should be seeing steam from your outlet in approximately 60-90 seconds)
- 3. To set the temperature you want the cabin to reach, press the function button (3) once the steam is active. You will see a small °C to the right of the display. The large number in the middle of the display can be changed by pressing the arrows (4). The maximum temperature you can reach is 60°C. The average temperature in a steam room is usually between approximately 30 to 36°C subject to bathroom ambient air temperature.
- I. To set the length you wish the steam to run for, press the function button again (3) then use the arrows (4) to set your desired time. The maximum length that can be set is 60 minutes.
- Only steam for approximately 10-15 minutes per session at your desired temperature. Due to temperature, your body can overheat, dehydrate and cause light headedness. This is very important for both your health and wellness.
 - Correct Procedure when using steam is SHOWER FIRST this will open your skins pores and your shower cabin will be warm on use. Steaming without showering lowers benefits and not recommended. If you do so NEVER run your steam generation before use to warm the shower, this can cause damage to operating parts, isn't safe practice and will not warm your cabin. NEVER Shower and Steam at the same time.

Before using the steam room, always read the steam room and shower safety guide first.

Bathroom Electrical Zones



There are 3 bathroom electrical zones that have been distinguished in the IEE wiring guidelines and these are:

Zone 0 is the area inside a bath, basin or shower. It's characterised as 'any area within a bathroom that can hold water'. Any fitting or electrical appliance utilised inside zone 0 must be a maximum of 12 volts (SELV) and completely secured against both partial and total submersion in water (minimum of IPX7)

Zone 1 is the region straight above zone 0 to the height of 2.25m from the base of the bath or shower. It covers the width of the shower cabin or length of the bath. Consider zone 1 to be the 'splash zone', where a fitting or electrical appliance is probably going to get exceptionally wet, very rapidly, however would not be totally immersed in water. Any fitting or electrical appliance inside zone 1 must be IPX4 (splash proof) or have a limit of 12v (SELV) with the transformer situated past zone 2.

Zone 2 is the area extending to 600mm outside of the bath or shower, be that above or to the sides of each. This is commonly the region which is least likely to get wet however there is a likelihood for it to be splashed. Any fitting or appliance inside zone 2 has to be IPX4 (splash proof) or have a maximum of 12v (SELV) with the transformer situated past zone 2.

Outside zones (Beyond Zone 2)

At the point where the size of a bathroom goes past zones 0, 1 and 2, portable electrical appliances can be utilised if their cord length doesn't allow them to be used in zone 2. For example, a hairdryer can be used in the outside zones provided its extended length doesn't enable it to be used in zone 2. Despite the fact that installing electrical appliances past zone 2 is allowed without an IP number, it is recommended that electrical appliances have some type of protection from moisture.

The Ingress Protection or IP number denotes the amount of mechanical and moisture protection an electrical appliance has. The 'IP' notation is followed by 2 numbers that show a numerical degree of mechanical and moisture protection.

The higher the number, the better the assurance it has against moisture/damage. If an appliance does not have an IP number it should never be used in zones 0,1,2 or anywhere that has a wet or damp environment.

All electrical circuits inside a bathroom must be protected by an RCD (residual current device), commonly known as a circuit breaker, not surpassing 30mA. RCD's ascertain when an electric current is not functioning normally and break the flow of the current if necessary, to guarantee that you are safe whilst using it.

Precaution should always be taken when introducing any electric appliance into a bathroom. We always advise using a registered bathroom fitter or electrician.

*The information on this page is for guidance only and you should always refer to the current IEE regulations of a qualified fitter or electrician to guarantee you are aware if the latest regulations and codes of practice.


WEEE Compliance Statement

The UK Waste Electrical and Electronic Equipment (WEEE) regulations came into force on 2 January 2007. Under this new legislation, producers of electrical and electronic equipment (EEE) have to fulfil certain obligations.

Under the WEEE directive Insignia is considered the producer of certain products we supply and in line with the demands of the legislation we are pleased to offer the opportunity to return these products to us for treatment and recycling.

Insignia products will generally have an identifying mark and the common crossed out wheelie bin label. We accept returns of all products carrying the Insignia brand. All other products are either considered outside the scope of WEEE or Insignia is not technically the producer of these products. Insignia also accepts historic like-for-like WEEE returns. All WEEE returned to Insignia will be recycled in appropriate treatment and recycling centres in accordance with the legislation. If you wish to return any products to us, please send your item(s) to our head office.

Company Contract No. 326457 WEEE Producer No. CBDU64227



LABELING

Products labelled with the WEEE symbol (a crossed out "waste bin") indicate that the final user should not discard this product along with other household waste, but that it must be collected and treated separately.



Returns Address for WEEE

9a Deans Road, Old Wolverton, Canon Industrial Park, Milton Keynes, Buckinghamshire, MK12 5NA, UK


EU – Declaration of Performance

Insignia declares that all its products complies with the essential requirements and other relevant provisions of Directive 305/2011/EC. A copy of the Declaration of performance is available from www.insigniarange.co.uk/ce.aspx

Insignia[™] is a registered trademark of Maclean International Ltd, 9a Deans Road, Old Wolverton, Canon Industrial Park, Milton Keynes, Buckinghamshire, MK12 5NA, UK

All images are subject to copyright. Images may not be used in any way shape or form with out written permission from Maclean International Ltd. Images are NOT permitted to be saved, printed or uploaded. Violation of copyright laws are punishable by law.

All images are registered with ImageTraker



	Room Control B018BT		
Rating:	AC220-240 50/60Hz	3KW	
凸			

Insignia[™] is a registered trademark of Maclean International Ltd

All images are subject to copyright. Images may not be used in any way shape or form with out written permission from Maclean International Ltd. Images are NOT permitted to be saved, printed or uploaded. Violation of copyright laws are punishable by law.