


Measuring Guide

NOTE: MEASUREMENTS TO BE CONDUCTED FROM INSIDE OF THE GARAGE LOOKING OUT.



- ① From the inside of the garage looking out. Measure from the top of the opening to the floor in mm.
- ② From the inside of the garage looking out. Measure from left to right of the opening in mm.

