

Birkdale Manufacturing Group Ltd Unit 1 Dunlop Way Scunthorpe North Lincolnshire DN16 3RN

01724 282171 sales@birkdale.co.uk

## Roller Door Preparation Guide.

This preparation guide gives you the information needed to ensure that your Birkdale Roller Door is installed in a timely but safe and tidy environment.

Please read this guide carefully and adhere to each section.

## Access to Property

Installers will need a clear and safe route from their vehicle to the point of installation. Clear all debris and tripping hazards from their pathway to ensure safe delivery.

## Working Area

To install a Birkdale Roller door, a clear working area all around the installation point is needed, equal to the full width of the doors opening & 2000mm back from the front of the garage door, ensuring clear unobstructed access.

## Electrics

Your Birkdale Roller Door requires power for operation this will need to be a single 13Amp socket outlet on the wall of your garage within 1000mm from the front of the opening on the same side as your motor is located. Birkdale always advise that a certified professional is used to change/install power points.

