


Measuring Guide



1
From the inside of the garage looking out. Measure from the top of the opening to the floor in mm, 3 measurements top middle and bottom, using the narrowest measurement

2
From the inside of the garage looking out. Measure from left to right of the opening in mm, 3 measurements top middle and bottom.

3
Measure the right and left reveal.

4
Measure the head room above the lintel.

5
Determine the position of your new garage door, between or behind the aperture.

* Doors sizes on line over frame measurement. Frame sizes for each product or as follows:

- Canopy, Frame uprights 54mm, frame head 45mm
- Retractable, Frame uprights 70mm, frame head 45mm
- Side Hinge, Frame uprights 50mm, frame head 50mm
- Sectional, Frame uprights 85mm, frame head 120mm
- Roller, (Single door) Frame uprights 70mm, frame head 300 mm, (Double door) Frame uprights 90 mm, frame head 300 mm (Single door up to 2500)

www.cardale.com

T 0800 533 5700

Head Office, 25 Matilda Street, Sheffield City Centre, Sheffield S1 4QG